



# CBU-CEFL

# Ceiling Flush Mount Passive Infra Red (PIR) Occupancy Detector & Photocell

Input: 220-240 Vac 50Hz CAS MBI

PLEASE READ THESE INSTRUCTIONS BEFORE INSTALLING THE PRODUCT NOTE: CBU-CEFL is only compatible to work with CASAMBI enable equipment

This flush mounted CBU-CEFL is suitable for easy mounting through a 73/75mm diameter hole

into a ceiling void which is at least 78mm deep. Configurable for any room occupancy style, via the free to download Casambi APP on Google Play or Apple APP Store.



## INSTALLATION

To be installed by a competent person with reference to BS 7671 or equivalent local standards. If in doubt consult a qualified electrician.

- Plan where the CBU-CEFL is to be located (see diagram 1). Switch off supply and check for hidden cables and pipes. Make a 73/75mm diameter hole through a standard ceiling board.
- The CBU-CEFL should be connected as shown in diagram 2:
  - L Live in. N Neutral in.
- Ensure both springs are fitted to the moulding in the correct orientation (see diagram 3).
- Push the CBU-CEFL into the ceiling void, making reference to diagram 4.

# OPERATION

To check the operation of the CBU-CEFL:

- Turn on the supply then after 20 seconds if the sensor has recognised movement of a person within its zone of detection the integral red LED on CBU-CEFL will stay illuminated for 4 seconds before the red LED turns off.
- Thereafter, every time movement is detected by CBU-CEFL the integral red LED will stay illuminated for 4 seconds.

The control also features adjustable time out (time lag) control and daylight threshold control which are configured by the Casambi APP.

## **PRECAUTIONS**

- Do not place the CBU-CEFL near heat sources, fans or in ventilated ceiling voids.
- CBU-CEFL can be wired in parallel (sharing the same Live and Neutral).
- Do not place close to, or positioned such that, any light source points directly into the CRU-CEL.
- Ensure wires and cables are securely held within the connection terminals.
- The CBU-CEFL should be protected by a 5 or 6 Ampere mcb or fuse.
- Disconnect the CBU-CEFL from the circuit before performing insulation testing of the wiring circuit.

# **TECHNICAL DETAILS**

INPUT	
220 - 240Vac	
50Hz	
0.05A	
0.05A	
RADIO TRANSCEIVER	
2.4 2,483 GHz	
+4 dBm	
OPERATING CONDITIONS  Note: The temperature difference between the detection target and the background must be at least 4 °C.	
-20 +40 °C (lout 0.05 A)	
+70 ℃	
-25 +75 °C	
0 80%, non cond.	
CONNECTORS	
0.5mm² - 2.5mm² solid or stranded	
6-7mm	
0,4 Nm/4 Kgf.cm	
MECHANICAL DATA	
79mm x 85mm x 85mm	
95g (unpacked)	
IP20	
Built-in Class 2	
Flame-retardant polycarbonate	
Matt /White (RAL 9003)	
Built-in Class 2	
CONFORMITY AND STANDARDS	
EN60669-2-1:2004 inc. A12:2010	
EN60669-2-1:2004 inc. A12:2010	
EN60669-2-1:2004 inc. A12:2010	
Complies with WEEE and RoHS directives	

## **5 YEAR WARRANTY**

CBU-CEPL comes with a 5 year warranty from the date of manufacture and is CE marked.













